Light signals

On ground	Light mode	In flight
Authorised to take off if pilot is satisfied that no collision risk exists	Green	Authorised to land if pilot is satisfied that no collision risk exists
Authorised to taxi if pilot is satisfied that no collision risk exists	Green flashing	Return for landing
Stop	Red	Give way to other aircraft and continue circling
Taxi clear of landing area in use	Red flashing	Do not land Aerodrome unsafe
Return to starting point on aerodrome	White flashing	

VFRG version 8.0 521